



METHOD STATEMENT

1. Mark location of tie on timber.
2. If required pre drill using a pilot drill of specified size to aid penetration.
3. Fast Flex fixings to be driven using a power support tool in a hammer drill
4. Spacing of ties and minimum penetration into the masonry will depend on the loading required
5. Make good at surface of all holes and leave ready for any decoration.

Notes : Unless specified otherwise the following criteria are to be used.

- a. 8 mm Fast Flex ties are to be used.
- b. A 5 or 6mm pilot drill is to be used in hard timber or when required to obtain the required penetration into the masonry.
- c. Where a specific loading is required a test unit can be used to measure the pull outs achievable at various depths of penetration.