



METHOD STATEMENT

1. Locate and mark the positions of joists on the external wall.
2. Drill clearance hole (normally 12 mm) through masonry in line with the centre of the joists.
3. Ensure that the hole lines up with the joist and continue to drill the hole through the first joist.
4. Blow out hole to clear any dust or debris.
5. Place support tool over the Bow Flex and drive the tie into the second joist for a minimum depth of 50mm.
6. Inject Resin or Bond Flex cementitious grout into the hole to completely fill it.
7. Make good at surface of all holes and leave ready for any decoration .

Guidance Notes : Unless specified otherwise the following criteria are to be used.

- a. Minimum penetration into the timber is 50mm.
- b. Horizontal spacing is 600mm between ties.