



METHOD STATEMENT

1. Mark location of tie on timber batten.
2. Hold timber batten in correct position against the wall.
3. Pre drill through batten, insulation and into wall using a pilot drill of specified size to a depth of 10mm more than the length of the fixing to be used.
4. Fast Flex fixings to be driven using a power support tool in a hammer drill.
5. Spacing of fixings and minimum penetration into composite timber will depend upon the loading required and the batten spacing.

Notes : Unless specified otherwise the following criteria are to be used.

- a. 8mm Fast Flex ties are to be used.
- b. A 5 or 6 mm pilot drill is to be used.
- c. The maximum allowable spacing between battens is 600mm.
- d. The maximum allowable spacing between ties is 600mm.
- e. Where a specific loading is required a test unit can be used to measure the pull outs achievable at various depths of penetration.